



### **InstaGen OFGEM Guide**

These photos are required as evidence of the following qualifying criteria:

➤ **Hologram sticker x 1**

- This needs to be stuck to either the CCA Tap device, enclosure cover/lid of the CCA Tap device or the inverter.
- Please ensure the photo is clear and the barcode/serial number can be clearly seen in the photo.

➤ **Panel identification & barcode photos (serial number & InstaGen logo)**

**Please Note** – these photos need to be taken **before** installing the panels

- Serial number: a clear photo of each serial number for all panels used per job
- InstaGen logo: a clear photo of the InstaGen logo for all panels used per job

➤ **Tigo (two screenshots are required)**

1) System View

- Click on “System View” below the VIEW tab on the Tigo monitoring platform and capture a screenshot of this page.

2) Info

- Click on “Info” below the VIEW tab on the Tigo monitoring platform and capture a screenshot of this page.

➤ **Tigo Optimisers (on all panels)**

- Photos of the optimisers fitted to each panel