

InstaGen Inverter Configuration Guide Manual

STEP 1

Check & Operation

Check List:

- Inverter ground wiring
- Communication module insertion
- COM2 connector insertion

START



Operation order:

1. AC insurance (if any)
2. AC circuit breaker
3. Inverter PV DC switch


If everything is ready, then please download [InstaGen APP](#).



Official Website

STEP 2

Device Direct Connection



Way 1:
Connect to the inverter's
WiFi


- 1. Search the inverter Wi-Fi on your phone;
✓ Name as WIFI-APXXXXXX, The last few digits of the Wi-Fi name are the same as the inverter SN.
✓ Please keep the Duocom connected before the operation.
- Connect it and back to InstaGen APP
- Login by installer role (Default password: 123456)

Way 2:
Connect via LAN

- Connect all the devices to the same local area network by wire or wireless
- Back to InstaGen APP and login by installer role (Default password: 123456)

STEP 3


Quick Configuration & WiFi




- Follow the 'Quick Configuration' to set the inverter
- Connect the inverter to customer's WiFi

STEP 4

Add Plant & Account



Login to your organization account.
(You can get it from your upper class organization.)



- Create the plant with customer's info (The customer will receive their account by the email you filled in.)
- Add the inverter into the plant (You can get the SN number and check code on the nameplate.)

END